


Category	Electrical Appliances
Product name	Mains Adapter used with Philips Products
Product Description	Mains Adapter
Picture	 <p>Model AY4132/05</p> <p>Model DSA-9W-09 FUK Model DSA-9W-05 FUK</p>
Risk Description	If you own one of the above products please switch off the mains power supply and check that the cover of the adapter is firmly attached. Then remove the adapter to check the date code printed near the connecting pins. If the date code on the adapter ends in 07 or 08 it is affected by this warning. Stop using it immediately and call the freephone number below to obtain a replacement mains adapter free of charge.
Affected Products	Philips Photo Frame Model: 7FF2FPAS/05 sold since July 2008 Philips Portable DVD players Models: PET716/05, PET716S/05, PET719/05, PET723/05, PET816/05, DCP750/05, DCP850/05, DCP951/05 sold since July 2007
Identifying Your Product	You can find the model number on the back of your product. Philips has identified a manufacturing defect with the mains adapters supplied with the above products. In extreme cases this may result in the cover becoming detached exposing live electrical parts. To ensure that all our products meet high standards of quality and safety Philips has decided to voluntarily recall the affected mains adapters. THIS RECALL ONLY AFFECTS THE ADAPTERS. THE REST OF THE PRODUCT IS NOT AFFECTED. The adapters affected can be identified by the labels shown on the right.
Instructions	To claim your replacement or if you have any questions please call Philips on: Freephone: UK 0800 331 6050 or IRELAND 1800 818834
Date	09/03/2009